Remote control

ℹ The symbols in the display are visible depending on the settings.

Setup

Resend / data transmission

Cooling

Sleep function

Fan level

Heating
Automatic mode

Temperature

Circulated air

18 ℃

00:00

Time

Timer
On / Off time

ON
OFF 07:00

13:15

Mode
Operating mode selection button
– Cooling
– Heating
– Automatic
– Circulated air

On / Off switch

Fan level
– low
– medium (not in heating mode)
– high

Temperature selection buttons
16 – 31 ℃
In 1 ℃ steps

Time
selection button

Time setting
Setting for clock time and timer

Sleep function
(in cooling mode only)
Ultra-quiet fan operation
by reducing the speed of both fans

Resend
Retransmit data

Ambient lighting
The lighting is dimmed by pressing
and holding down the button. Pressing it
again deactivates or activates the lighting.

Reset
Resets the remote control
to the factory settings.

Truma
Aventa

Timer selection buttons
Switch-on/switch-off time
can be set up to 24 hours in advance

Setup button
Tuning the remote control
and the IR receiver