NSTRUCTION MANUAL TABLE FAN



8520964

Instructions

Fan power button:

One press: switch in the first gear Twice press: switch in the second gear

Three press: turn off the fan

Spray power button:


One press: spray continuous

Twice press: intermittently (spray 3s, stop 3s)


Three press: turn off the spray

The fan and spray can be used about 1,5 hours, claims takes a full charge in just 3 hours. When the water tank runs out, the power will stop spraying. Turn off the fan, the power will stop spray and fan.


Please charge the fan 2 hours before first use.




Steps



1 Turn counterclockwise to open lid



(2) Add water into the (3) Turn the cover water tank



clockwise up and connect the power supply



(4) Click the buttons to start

Cotton swab replacement



① Draw the filter bar and replace the filter



② Pay attention to the spring in bottom when replacing

Attention

If you find several water drop accumalating, that means normal phenomenon at the model are working. Use dry paper to wipe it out. If the water tank is not used for a long time, keep it dry and clean to avoid bacterial growth. Do not add alcohol, aromatheraby, essence, essential oil and other liquids to affect the normal operation of humidifier. After using for a period of time, if there is a small amount of dirt on the inner wall of the tank, it is recommended to use a soft cotton bloth and a small amount of soda powder to wipe the inner wall of the water tank. When cleaning the product, please do not rinse directly with a water tap to avoid short circuiting.

Unplug the power plug when refilling water and cleaning.

Accessories

Guide Micro USB cable Cotton swab

BO-CAMP.COM NL-5126 PT 4